

## Your mobile .....



<sup>(1)</sup> Depending on your network operator.

OT-355D  
ALCATEL  
mobile phones

### 1.1 Keys

- Navigation key
  - Confirm an option (press the middle of the key)
  - Access to menu (short keypress)
  - Show/hide shortlist menu(long keypress)
- Pick up
  - Send a call
  - Access call memory (short keypress)
  - Access to Fake call (long keypress)
- Switch on/Switch off the telephone (long keypress)
- End call
- Return to the idle screen
- Left softkey
- Right softkey
- Access your voicemail (long keypress)
- Input the "#" in Idle
- In idle screen:
  - Long/short keypress: Lock/Unlock the keypad
- In edit mode:
  - Short keypress: input space
  - Long keypress: switch language
  - Fn key + Space: switch input mode

1

## 5 Messages .....

### 5.1 Messages: Text/Multimedia message

#### 5.1.1 Create message

From the main menu select **"Messages"** to create text/multimedia message.

You can type a message and select to send it to a recipient in either the SIM1 or SIM2 directory.

You can type a message and you can also modify a predefined message in **Templates** or customise your message by adding pictures, photos, sounds, titles, etc (only available while editing a MMS). While writing a message, select **"Options"** to access all the messaging options.You can save your messages that you send often to **Drafts** or **Templates** (MMS only).

#### 5.1.2 Inbox/Outbox

You can check the details of messages contained on either SIM card from Inbox/Outbox.

### 5.2 Email <sup>(1)</sup>

Your phone has an email client with the settings predefined for a few popular email services like – GoogleMail, Windows live, Yahoo, AOL,etc<sup>(2)</sup>.

## 6 Directory .....

### 6.1 Consulting your directory

To access the **Directory** from the main screen, press the key and select the icon.

You can check contact details on either SIM1/SIM2 and also Copy between SIM1/SIM2 and the Phone directory. From **"Directory Management"**, select the **"Default Storage"** option and choose your preferred SIM card on which to save information.

<sup>(1)</sup> HTML email and image in email not supported.

<sup>(2)</sup> Depending on your operator.

8

### 6.2 Adding a contact

Select the contacts list in which you wish to add a contact to, press the **"Options"** softkey, select **"Add contact"** then Save.

## 7 Fake call .....

Protect yourself from annoying situations with the **"Fake call"**. In this menu you can set **"Caller name/nb"**, **"Call time"** and **"Ringtone"**.

When the timer reaches, the phone will ring and display like receiving a real phone call. Press key, pretend answering a call, the screen will display just like have an ongoing call. Press key, pretend to reject the call, the call will terminate automatically.

## 8 FM Radio .....

Your phone is equipped with a Radio <sup>(1)</sup> with RDS functionality. You can use the application as a traditional Radio with saved channels or with parallel visual information related to the radio program on the display, if you tune to stations that offer Visual Radio service. You can listen to it while running other applications.

## 9 Internet<sup>(2)</sup> .....

### 9.1 WAP

Access WAP options: **Homepage**, **Bookmarks**, **Go to URL**, **Recent pages**, **Offline pages**.

<sup>(1)</sup> The quality of the radio depends on the coverage of the radio station in that particular area.

<sup>(2)</sup> Depending on your network operator. May cause additional network charges for data flow to provide this service. Extra fees might also be charged in roaming states.

9



In idle screen:

- Press to access shortcuts
- Fn + P: access to Profiles
- Fn + Q: access to Clock
- Fn + S: access to Notes

In edit mode:

- Press once to input top-half character.
- Press twice to lock top-half inputting mode, then press once to unlock top-half inputting mode.

Long keypress: access to Dictionary.



In edit mode:

- Short press: popup symbol page to select special character by navigation key
- Long press & Fn+SYM: popup smileys page to select special smileys by navigation key



Delete one by one (short keypress)



Delete one by one quickly (long keypress)



Switch the uppercase and minuscule (in edit screen)



Return a cursor to the next line.

### 1.2 Main screen icons <sup>(1)</sup>

#### Battery charge level

**Vibrate alert:** Your phone vibrates, but does not ring or beep with the exception of the alarm.

#### Headset connected.

#### Keypad locked.

**SIM1(2) Call forwarding activated:** your SIM1(2) calls are forwarded.

<sup>(1)</sup> The icons and illustrations in this guide are provided for informational purposes only.

2

### 9.2 Weather .....

Your phone is equipped with a weather function for consulting up to 3-day forecast of favorite cities.

### 9.3 News .....

It is a huge time saver providing news updates from a website in a simple form. Once subscribed to a channel, it gives you the ability to track and manage all your favorite RSS content on your mobile phone at anytime, anywhere!

Available options:

View

Message title or message summary of a channel with URL will be shown.

Update

Refresh the content of a channel.

Create channel

Create a new channel with name and URL.

Delete

Delete the channel.

Edit

Edit the name or URL of a channel.

Update all

Refresh all channels.

Settings

Select a regular interval to retrieve updates automatically, as well as a WAP account to connect to.

Enable/Disable

Activate auto-update or not to all channels.

all auto-update

## 10 ICE contact .....

ICE (in case of emergency) are 3 numbers emergency services can call if you have an accident, you can also add useful information such as blood type, allergy. Access to **"ICE contact"** menu from main menu and below options are available: View, Add/Edit, Delete.

## 11 Games .....

Your phones includes some games, Select **"Game settings"**, it allows you to manage settings, in which you may set background audio and vibration alert.



Alarm clock.



SIM1(2) Level of network reception.



SIM1(2) Voicemail message arrived.



Missed calls.



Radio is on.



Stopwatch is active.



WAP alerts <sup>(1)</sup>.



Roaming.



SIM1(2) GPRS connection status (Gray - Activated).



SIM1(2) GPRS attached.



Message receipt in progress.



Silence mode: your phone neither rings, beeps nor vibrates.



Message unread.



Message list is full: your terminal cannot accept any new messages. You must access the message list and delete at least one message on your SIM card.



Flight mode.



SIM1(2) Call forwarding activated: your SIM1(2) calls are forwarded.

<sup>(1)</sup> Depending on your network operator.

<sup>(2)</sup> Contact your network operator to check service availability.

3

## 12 Camera .....

Your mobile phone is fitted with a camera for taking photos that you can use in different ways:

- Store them in your "Media album/My creations".
- Send them in a multimedia message (MMS) to a mobile phone or an email address.
- Send them directly by Email.
- Customise your main screen.
- Select them as incoming call image to a contact in your directory.

## 13 Profiles .....

With this menu, you may personalise ringtones for different events and environments.

## 14 Media album .....


You will have an access to all audio and visual files stored in phone or in Medium Album. You can access a number of items with this option: **My audios**, **My images**, **Unknown files** and **Memory status**.

10


## 2 Getting started .....

### 2.1 Set-up

#### Removing or installing the back cover




#### Installing or removing the battery



4

#### Inserting or removing the SIM card



Place the SIM card with the chip facing downwards and slide it into its housing. Make sure that it is correctly inserted. To remove the card, press the bottom and slide it out. Please power off your phone before you remove the SIM card.

### 2.2 Power on your phone

Hold down the key until the telephone powers on.

### 2.3 Power off your phone

Hold down the key until the telephone power off.

5

## 15 Services .....

Contact your network operator to check service availability.

## 16 Others .....

### 16.1 Calendar .....

Once you enter this menu from main menu, there is a monthly-view calendar for you to keep track of important meetings, appointments, etc. Days with events entered will be marked in color.

### 16.2 Calculator .....

Access this feature by selecting **"Calculator"** from the main menu.

Enter a number, select the type of operation to be performed using the navigation keys, and enter the second number, then press key or left softkey to display the result.

### 16.3 Notes .....

You can create a note in text or voice format by accessing **"Notes"** from main menu.

### 16.4 Tasks .....

Enable you to easily manage and track the progress of an task with priorities. All the tasks will be sorted by due date.

### 16.5 Clock .....

Standby time will be less if using dual SIM function.

#### 16.5.1 Alarm

Your mobile phone has a built-in alarm clock with a snooze feature.

#### 16.5.2 Clock

Allow you to have settings of date and time, including 12/24h format.

11

## 3 Calls .....

### 3.1 Making a call

Dial the desired number then press the key to place the call. If you make a mistake, you can delete the incorrect digits by pressing the right softkey or key.

To hang up the call, press the key.

#### Making an emergency call

If your phone has network coverage, dial emergency number and press the key till tick "v" is shown, then move the cursor to your favorite destination and confirm with key.

### 3.2 Call memory

You can access your call memory by pressing the key from the idle screen, including the following options for either SIM card: **"Outgoing calls"**, **"Missed calls"**, **"Answered calls"**.

## 4 Menu arrange .....

Main Menu is designed to vary according to your preference.

#### Change the order

From main menu, press left softkey and select **"Move"** or long keypress key till tick "v" is shown, then move the cursor to your favorite destination and confirm with key.

#### Show/Hide

Access **"Menu arrange"**, press key till tick ("v") show or off, it will show/hide some main menu.

6

## 16.5.3 World clock

The World clock shows current local time and the time zone in different cities.

### 16.5.4 Stopwatch

The stopwatch is a simple application for measuring time with the possibility to register several results and suspend/resume measurement.

### 16.6 Converter .....

Unit converter and Currency converter.

ALCATEL is a trademark of Alcatel-Lucent and is used under license by TCT Mobile Limited.

All rights reserved © Copyright 2010 TCT Mobile Limited.

TCT Mobile Limited reserves the right to alter material or technical specification without prior notice.

Prolonged exposure to music at full volume on the music player may damage the listener's hearing. Set your phone volume safely. Use only headphones recommended by TCT Mobile Limited and its affiliates.

English - CJB2ISDALAAA

14

